



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **ALFA ROMEO**

MOD.

147

YEAR.

00 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the support of the servobrake in the engine compartment.

CENTRAL UNIT POSITION

The modular systems and the modules should be positioned under the dashboard, driver's side.

POWER SUPPLY

+30: connect to the positive end of the battery.
-31: connect directly to the car body.

IGNITION WIRE

+15/54: Connect to the 2 mm² ORANGE wire located in the wiring harness coming out of the connector of the ignition key.

DIRECTION INDICATORS

The electric system of the car has the direction indicators lines divided, so it is suggested to divide the following wires by means of 6 diodes: LIGHT BROWN/BLACK (ant. left), BROWN/VIOLET (ant. right), BROWN/WHITE (lat. left), BROWN/YELLOW (lat. right), these wires are located in the 40 way light blue connector and BROWN/BLACK (post. left), BROWN/VIOLET (post. right) are located in the 40 way black connector in the fuse box.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the the 1 mm² GREY wire located in the 26 way connector inside the driver's side door.

Front window, passenger's side:

cut the 1 mm² VIOLET/BLACK wire located in the wiring harness behind the sill cover driver's side.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the RED/WHITE wire (lock) and to the LIGHT BLUE wire (unlock) located in the 40 way black connector under the fuse box.

IMMOBILISATION POINT

Fuel pump

Cut the 2 mm² VIOLET/YELLOW wire located in the bundle of cables behind the sill cover, driver's side.

STARTER

+50: Cut the BROWN wire located in the wiring harness coming out of the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support grill, driver's side.

DOORS SWITCH

Connect to the LIGHT BLUE/YELLOW wire located in the wiring harness coming out of the lamp.

BOOT SWITCH

Connect to the BROWN/GREY wire coming out of the boot lamp.