



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MOD.	YEAR.	PETROL	DIESEL
AUDI	A2	00 →	<input checked="" type="checkbox"/>	<input type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens on the support of the shock absorber passenger's side. Pass the cables through the original rubber core hitch located on the panel that divides the engine compartment and the passenger's compartment, passenger's side.			
CENTRAL UNIT POSITION	Position the modular systems and the modules under the dashboard, driver's side.			
POWER SUPPLY	+ 30 : connect to the 4 mm ² RED wire located in a multiway connector at the entrance of the fuse box. - 31 : connect with a ring terminal directly to the car body.			
IGNITION WIRE	+ 15/54 : connect to the RED/GREEN wire at the position nr. 17 located in the 17 way black connector, on the connectors holder plate under the moquette on front of the driver's seat.			
DIRECTION INDICATORS	Connect to the BLACK/WHITE and BLACK/GREEN wires in the wiring harness behind the sill cover driver's side.			
ELECTRIC WINDOWS	Negative control signal The closing of the electric windows is obtained timing to 24s the same GREY/GREEN wire used for the closing of the doors.			
CENTRAL DOORS LOCKING	Negative control signal Connect to the GREY/GREEN wire (lock) and GREY/VIOLET wire (unlock) located in the wiring harness directly coming out from the lock inside the driver's side door.			
IMMOBILISATION POINT	Fuel pump Cut the BLACK/BLUE wire located at the position nr. 4, in the 10 way grey connector, behind the driver's side bulkhead.			
STARTER	+ 50 : Cut the RED/GREEN wire located in the wiring harness coming out of the ignition key.			
BONNET SWITCH	Install an additional switch on the front headlamp support plate, driver's side.			
DOORS SWITCH	Connect to the BROWN/WHITE wire at the position nr. 2 in the 12 way black connector coming out of the modular system located under the moquette on front of the drivers seat.			
BOOT SWITCH	Connect to the BROWN/PINK wire at the position nr. 11 located in the 16 way LIGHT BROWN connector coming out of the modular system under the moquette on front of the driver's seat.			