



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

**AUDI**

MOD.

**A3 \***

YEAR.

**02 →**

PETROL   
DIESEL

\* Models with original equipment keyless entry system.

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the ABS bracket. Pass the cables through the rubber sleeve located on the panel that divides the engine compartment and the passenger's compartment near the shock absorber, driver's side.

#### CENTRAL UNIT POSITION

Position the modular systems and the modules behind the fuse box, under the dashboard, driver's side.

#### POWER SUPPLY

**+30:** connect to the 4 mm<sup>2</sup> RED wire located in the general supply wiring of the fuse box.  
**- 31:** connect with a ground terminal on the left, under the dashboard, driver's side.

#### IGNITION WIRE

**+15/54:** connect to the 2 mm<sup>2</sup> BLACK wire located in a multiway connector in the central part of the fuse box on the left of the dashboard.

#### DIRECTION INDICATORS

Connect to the 1,5 mm<sup>2</sup> BLACK/WHITE and BLACK/GREEN wire located under the lateral left, driver's side.

#### ELECTRIC WINDOWS

##### Negative control signal

The closing is obtained timing at 24s. the GREY wire, at the position nr. 1, in the light brown connector, behind the left lateral bulkhead, driver's side.

#### ACTIVAT./DEACTIVATION CONTROLS

##### Connections antitheft/vehicle

Art. 3800	Vehicle	Position
YELLOW/BLACK	GREEN/BLACK	Pos. nr.2, 11 way black connect., white insert
GREY/BLACK	ground	car body
VIOLET	ground	car body
ORANGE	ground	car body
VIOLET/WHITE	ground	car body
ORANGE/WHITE	ground	car body

Refer to the **diagram nr. 160.**

#### IMMOBILISATION POINT

##### Fuel pump

Cut the 1,5 mm<sup>2</sup> BLUE/RED wire located in the wiring harness under the left sill cover, driver's side.

#### STARTER

**+50:** Cut the 1,5 mm<sup>2</sup> BLACK/RED wire located in the wiring harness coming out of the connector of the ignition key.

#### BONNET SWITCH

Install an additional switch on the headlamp support plate, driver's side.

#### DOORS SWITCH

Connect to the BROWN/WHITE wire located in the wiring harness under the lateral left sill cover going to the rear.

#### BOOT SWITCH

Connect to the 1 mm<sup>2</sup> WHITE/BLACK wire, at the position nr.4, of the 6 way black connector behind the door on the left of the boot.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°160

Diagram to connect art. 3800 on  
**AUDI A3** year 2002

