



SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	AUDI	MOD.	A3*	YEAR	03 →	PETROL <input checked="" type="checkbox"/> DIESEL <input type="checkbox"/>
------	-------------	------	------------	------	-------------	---

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION	Position the compact alarms and the sirens on the support near the locking of the bonnet.
CENTRAL UNIT POSITION	Position the modular systems and the modules under the central tunnel or under the passenger's side seat.
POWER SUPPLY	+30: connect directly to the positive pole of the battery. -31: connect directly to the ground terminal located behind the driver's side sill cover.
IGNITION WIRE	+15/54: connect to the 2 mm ² BLACK wire, in the wiring harness coming out of the fuse box located on the left side of the dashboard.
DIRECTION INDICATORS	Connect to the BLACK/WHITE wire at the position nr. 11 in the 21 way light brown connector, marked "D", BLACK/GREEN wire at the position nr.10 in the black connector marked "B", BLACK/WHITE wire at the position nr.8 and BLACK/GREEN wire at the position nr.6, in the 12 way black connector, marked "A". To make the connection it is necessary to separate the lines by means of diodes.
ACTIVAT./DEACTIVATION CONTROLS	Connections antitheft/vehicle Refer to the fitting diagram nr.187 .
IMMOBILISATION POINT	Fuel pump Cut the BLACK/BLUE wire in the wiring harness coming out of the fuse nr.29, in the fuse box located on the left side of the dashboard.
STARTER	+50: Cut the 0,35 mm ² RED/BLACK wire, at the position nr.1, in the 12 way black connector, marked "G", in the central located under the driver's side dashboard.
BONNET SWITCH	Connect to the BROWN/LIGHT BLUE wire, in the wiring harness coming out of the bonnet lamp.
DOORS SWITCH	Connect to the BROWN/WHITE wire in the wiring harness behind the lateral bulkhead, driver's side.
BOOT SWITCH	Connect to the BLACK/RED wire, at the position nr.8, in the wiring harness coming out of the 17 way light brown connector, in the central located in the rear covering of the passenger's side boot.

FITTING DIAGRAM NR.187

Diagram to connect art. 3800 on
AUDI A3 year 2003

