



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	AUDI	MOD.	A6	YEAR	98 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>									
<b>CENTRAL UNIT POSITION</b>									
<b>POWER SUPPLY</b>									
<b>IGNITION WIRE</b>									
<b>DIRECTION INDICATORS</b>									
<b>ELECTRIC WINDOWS</b>									
<b>CENTRAL DOORS LOCKING</b>									
<b>IMMOBILISATION POINT 1</b>									
<b>IMMOBILISATION POINT 2</b>									
<b>BONNET SWITCH</b>									
<b>DOORS SWITCH</b>									
<b>BOOT SWITCH</b>									