



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

CHRYSLER

MOD.

VOYAGER

YEAR.

02 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens under the driver's side headlamp.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, on the left, under the steering wheel.

POWER SUPPLY

+30: Connect to the WHITE/RED wire in the 4 way connector, on the left of the rudder pedals.

-31: Connect to one of the ground terminals.

IGNITION WIRE

+15/54: Connect to the wire, at the position nr.3, in the 5 way connector, under the covering behind the steering wheel.

DIRECTION INDICATORS

Connect to the WHITE/GREEN wire at the position nr.1, to the WHITE/GREEN wire at the position nr.2, to the WHITE/BROWN wire at the position nr.3, to the WHITE/BLACK wire at the position nr. 4, in the 34 way black/green connector, in the central placed on the left of the rudder pedals.

Note: divide the lines with diodes.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the ORANGE/WHITE wire at the position nr. 8, in the 16 way green connector, on the driver's side push button panel.

Front window, passenger's side:

cut the ORANGE/GREY wire at the position nr.4, in the 16 way green connector, on the driver's side push button panel or on the coming out of the driver's side door.

Rear window, driver's side:

cut the ORANGE/ BLUE wire at the position nr.3, in the 16 way green connector, on the driver's side push button panel or on the coming out of the driver's side door.

Rear window, passenger's side:

cut the ORANGE/GREY wire at the position nr. 5, in the 16 way green connector, on the driver's side push button panel or on the coming out of the driver's side door.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the VIOLET/GREEN wire at the position nr. 22, in the 34 way black/white connector, placed on the left of the rudder pedals. Refer to the **diagram nr. 158**.

IMMOBILISATION POINT

Fuel pump

Cut the BROWN wire, at the position nr.8, in the 20 way connector, placed in the fuse box and relay, in the driver's side engine compartment.

STARTER

+50: Cut the GREEN/ORANGE wire, at the position nr. 14, in the 34 way black/white connector, in the central placed on the left of the rudder pedals.

BONNET SWITCH

Connect to the VIOLET/BLUE wire at the position nr. 30, in the 34 way black/white connector, in the central placed on the left of the rudder pedals.

DOORS SWITCH

Connect to the VIOLET/YELLOW wire at the position nr. 5, to the VIOLET wire at the position nr. 6, to the VIOLET/WHITE wire at the position nr. 7, to the VIOLET/GREY wire at the position nr. 8, in the 34 way black/white connector, in the central placed on the left of the rudder pedals.

Note: Divide the lines with diodes.

BOOT SWITCH

Connect to the VIOLET/ORANGE wire, at the position nr. 29, in the 34 way black/white connector, in the central placed on the left of the rudder pedals.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N° 158

Diagram to make the central locking on
CHRYSLER VOYAGER year 2002

