



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

**CITROEN**

MOD.

**BERLINGO\***

YEAR

**01** →

PETROL   
DIESEL

\* Models with original equipment keyless entry system.

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side.

#### CENTRAL UNIT POSITION

Position the modular systems and the modules under, on the left of the dashboard, driver's side.

#### POWER SUPPLY

+ **30**: put on a cable terminal for fuse and relative fuse in one of the empty prearrangements located in the fuse box.  
- **31**: connect with a cable terminal directly to the car body.

#### IGNITION WIRE

+ **15/54**: connect to the wire at the position nr. 22 of the 26 way blue connector coming out of the BSI original central.

#### DIRECTION INDICATORS

Connect to the wires at the positions nr.14 and nr.15 in the wiring harness of the 16 way black connector coming out of the BSI original central.

#### ELECTRIC WINDOWS

##### Positive control signal

##### Front window, driver's side:

cut the WHITE wire coming out of the connector of the central of the automatism located under the driver's side dashboard, between the central tunnel and the steering column.

##### Front window, passenger's side:

cut the LIGHT BLUE wire marked nr. 608 directly in the wiring harness coming out of the serial push button.

#### ACTIVAT./DEACTIVATION CONTROLS

##### Connections antitheft/vehicle

It is suggested to refer to **diagram nr. 66**.

#### IMMOBILISATION POINT

##### Gasoil pump

Cut the wire marked nr. 121 located at the position nr. 13 of the 23 way grey round connector located above the BSI operating central.

#### STARTER CUT OFF

+ **50**: Cut the RED wire located in the wiring harness coming out of the 2 way connector of the central, placed on the right of the steering column.

#### BONNET SWITCH

Install an additional switch on the front headlamp support plate.

#### DOORS SWITCH

Connect to the GREEN wire at the position nr. 17 of the 26 way, blue connector, coming out of the BSI original central.

#### BOOT SWITCH

Connect to the GREY wire at the position nr. 12 of the 26 way, blue connector, coming out of the BSI original central.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N° 66

## CITROEN BERLINGO for 3800

- At the positions 3 and 4 there are the power wires of the doors actuators motors.
- At the positions 8 and 5 there are the lock/unlock controls (right and left side).
- At the position 12 there is the signal coming from the boot lamp.

### Original doors locking central

