



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

**REV. 00**

[www.cobra.it](http://www.cobra.it)

<b>MAKE</b>	<b>CITROEN</b>	<b>MOD.</b>	<b>BERLINGO*</b>	<b>YEAR</b>	<b>03</b> →		<b>PETROL</b> <input checked="" type="checkbox"/>
							<b>DIESEL</b> <input type="checkbox"/>

\* Models with original equipment keyless entry system.

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens on the driver's side wheel house, near the original horns.
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the dashboard, driver's side.
<b>POWER SUPPLY</b>	<p><b>+30:</b> connect with a cable terminal to a clamp marked '+30' in the feed rod located in the black box placed on the side of the battery, in the engine compartment.</p> <p><b>-31:</b> connect with a cable terminal to a clamp marked 'GND' in the feed rod located in the black box placed on the side of the battery, in the engine compartment.</p>
<b>IGNITION WIRE</b>	<b>+15/54:</b> connect to the 2,5 mm <sup>2</sup> LIGHT BLUE wire located in the connector coming out of the ignition key.
<b>DIRECTION INDICATORS</b>	Connect to the wires at the positions nr.13 and nr.14 coming out of the wiring harness of the 16 way black connector.
<b>ELECTRIC WINDOWS</b>	<p><b>Motor controls</b></p> <p>Information not available at the moment.</p>
<b>ACTIVAT./DEACTIVATION CONTROLS</b>	<p><b>Connections antithefts/vehicle</b></p> <p>Refer to the <b>fitting diagram nr. 186.</b></p>
<b>IMMOBILISATION POINT 1</b>	<p><b>Fuel pump</b></p> <p>Cut the LIGHT BROWN wire marked nr.1235 located in the more little wiring harness behind the driver's side sill cover.</p>
<b>IMMOBILISATION POINT 2</b>	<p><b>Relay pump supply</b></p> <p>Cut the LIGHT BROWN wire marked nr. 1235, at the position nr.11, coming out of the connector marked 'GRIS' placed in the fuse box, in the driver's side engine compartment.</p>
<b>STARTER</b>	<b>+50:</b> Cut the YELLOW wire located in the wiring harness coming out of the 3 way connector placed on the left of the steering column.
<b>BONNET SWITCH</b>	Install an additional switch on the front headlamp support plate, driver's side.
<b>DOORS SWITCH</b>	<p>Connect to the wire at the position nr. 32 of the green connector, inside the connection with white covering, in the fuse box bottom, under the driver's side dashboard.</p> <p><b>Note:</b> the polarity of the lamp is positive.</p>

**FITTING DIAGRAM NR.186**

Diagram to connect art. 3800 on  
**CITROEN BERLINGO** year 2003

