



SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MOD.	YEAR.	PETROL <input type="checkbox"/>	DIESEL <input checked="" type="checkbox"/>
CITROEN	JUMPY	02 →		<input checked="" type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment, behind the lights group, driver's side. Pass the cables through the original rubber sleeve located on the panel that divides the engine compartment and the passenger's compartment, above the shock absorber.			
CENTRAL UNIT POSITION	Position the modular systems and the modules under the dashboard, driver's side.			
POWER SUPPLY	+30: connect to the 4 mm ² RED wire at the entrance of the fuse box. -31: connect with a cable terminal directly to the car body.			
IGNITION WIRE	+15/54: connect to the 1,5mm ² PINK wire located in the connector on the left of the fuse box.			
DIRECTION INDICATORS	Connect to the 1 mm ² WHITE and LIGHT BROWN wires located in the wiring harness coming out of the connector of the lights switch.			
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the 2 mm ² WHITE wire. Front window, passenger's side: cut the 2 mm ² YELLOW wire. These connections must be made directly in the wiring harness on the coming out of the windows operating central.			
CENTRAL DOORS LOCKING	Negative control signal Connect to the LIGHT BROWN wire marked with the nr. 6291 located in the wiring harness coming out of the connector of the driver's side door. Refer to the fitting diagram nr.178 .			
IMMOBILISATION POINT	Gasoil pump Cut the wire coming out of the inertial switch located in the engine compartment.			
STARTER	50: Cut the wire at the position marked '+50' directly on the coming out of the ignition key.			
BONNET SWITCH	Install an additional switch on the front headlamp support plate.			
DOORS SWITCH	Connect to the YELLOW wire located in the wiring harness behind the left lateral bulkhead, driver's side.			
BOOT SWITCH	Connect directly to the control wire of the rear lamp. Some versions are not provided with the lamp so it is necessary to install an additional switch.			

FITTING DIAGRAM NR.178

Diagram to make the central locking on
CITROEN JUMPY year 2002

(for 3100-3900 series antithefts use the VIOLET/WHITE and ORANGE/WHITE wires)
 (for 7900 serie antithefts use the VIOLET/ORANGE)

