



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

CITROEN

MOD.

SAXO

YEAR.

01 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, passenger's side.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ **30**: connect to the wire marked BH08A, at the position nr. 1, of the 9 way brown connector, located on the coming out of the central doors locking unit.
- **31**: connect with the wire marked M6235, at the position nr. 2, of the 9 way brown connector located on the coming out of the central doors locking unit.

IGNITION WIRE

+ **15/54**: connect to the wire marked nr. 2194 located in the 2 way connector coming out of the ignition key.

DIRECTION INDICATORS

Connect to the GREEN wire marked nr. 2310 and to the GREEN wire marked nr. 234 located in the wiring harness coming out of the connector of the lights switch.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the LIGHT BROWN wire, at the position nr. 1, of the window control switch, driver's side.

Front window, passenger's side:

cut the LIGHT BROWN wire at the position nr. 1, of the window control switch, passenger's side.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the GREY wire marked nr. 6231 (unlock) and to the LIGHT BLUE wire marked nr. 6251 (lock) located in the wiring harness coming out of the 9 way brown connector, of the central doors locking unit.

IMMOBILISATION POINT

Gasoil pump

Cut the wire at the position D1 or D2 located in the 10 way brown connector, in the fuse box placed on the side of the battery, in the engine compartment.

STARTER CUT OFF

50: Cut the LIGHT BLUE wire located in the wiring harness coming out of the 2 way connector, placed along the steering column.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, driver's side.

DOORS SWITCH

Connect to the GREY wire marked nr. 307 located in the wiring harness behind the cover of the driver's side support.

BOOT SWITCH

Connect to the ORANGE wire located in the connector coming out directly from the boot light.