



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

DAEWOO

MOD.

LEGANZA

YEAR

99 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the support of the shock absorber, passenger's side.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ 30: connect to the 4 mm² RED wire located at the entrance of the fuse box.
- 31: connect with a cable terminal directly to the car body.

IGNITION WIRE

+ 15/54: connect to the PINK wire located in the wiring harness under the sill cover, driver's side.

DIRECTION INDICATORS

Connect to the LIGHT BLUE wire at the position nr. 4 and BLUE wire with BLACK references at the position nr. 5 located in the 6 ways white connector behind the driver's side bulkhead.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the ORANGE/BLACK wire located directly in the wiring harness outgoing from the serial push button.

Front window, passenger's side:

cut the BROWN wire.

Rear window, driver's side:

cut the GREEN wire.

Rear window, passenger's side:

cut the LIGHT GREEN wire.

Connections must be done in the wiring harness coming out of the driver's side door.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the LIGHT BLUE/WHITE wires with BLACK references (lock) and to the YELLOW wire (unlock) located in the wiring harness behind the sill cover, driver's side.

IMMOBILISATION POINT 1

Fuel pump

Cut the GREY wire with BLACK references located in the wiring harness behind the sill cover, driver's side.

STARTER

+50: Cut the PINK/BLACK wire at the position nr. 9 in the line marked "A" located in a multiway connector, in the fuse box inside the engine compartment.

BONNET SWITCH

Install an additional switch on the front headlamp support plate near the rubber grommet of the bonnet.

DOORS SWITCH

Connect to the WHITE wire with BLACK references located in the wiring harness behind the sill cover, driver's side.

BOOT SWITCH

Connect to the 0,5 mm² PINK/BLACK wire located in the wiring harness behind the sill cover, driver's side.