



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	<b>FIAT</b>	MOD.	<b>BRAVA*</b>	YEAR	<b>01</b> →	PETROL	<input checked="" type="checkbox"/>
						DIESEL	<input type="checkbox"/>

\* Models with original equipment keyless entry system.

**ALARM/SIREN POSITION** Position the compact alarms and the sirens on the support of the servobrake in the engine compartment.

**CENTRAL UNIT** Position the modular systems and the modules under the dashboard, driver's side.

**POWER SUPPLY**  
+ 30: connect to the 4 mm<sup>2</sup> RED wire located in the 2 way white connector in the fuse box.  
- 31: connect directly to the car body.

**IGNITION WIRE** + 15/54: connect to the 1,5 mm<sup>2</sup> ORANGE wire located in the wiring harness and coming out of the ignition key, alternatively to the 1mm<sup>2</sup> BLUE/RED wire located in the multiway connector in the fuse box.

**DIRECTION INDICATORS** Connect to the LIGHT BLUE and LIGHT BLUE/BLACK wires in the 4 way white connector on the original blinker push button.

**ELECTRIC WINDOWS**  
**Positive control signal**  
**Front window, driver's side:**  
cut the VIOLET/YELLOW wire at the position nr. 8, in the 20 way white connector on the ABI central located behind the glove compartment, passenger's side.  
**Front window, passenger's side:**  
cut the VIOLET/WHITE wire at the position nr. 9, in the 20 way white connector on the ABI central located behind the glove compartment, passenger's side.

**ACTIVAT./DEACTIVATION CONTROLS** **Connections antitheft/vehicle**

Art.3800	Vehicle	Position
YELLOW/BLACK	Pos. nr.1	8 way connector
GREY/BLACK		Positive
VIOLET		Positive
ORANGE		Positive
VIOLET/WHITE		Positive
ORANGE/WHITE		Positive

The 8 way connector of the radio set is located in the front roof lamp.

**IMMOBILISATION POINT** **Fuel pump**  
Cut the BROWN/WHITE wire located in the white connector of the right lower part of the fuse box.

**STARTER** +50: Cut the wire located at the position marked "+50" in the wiring harness coming out of the connector of the ignition key.

**BONNET SWITCH** Install an additional switch on the front headlamp support plate, driver's side.

**DOORS SWITCH** Connect to the BROWN/BLACK wire at the position nr. 2 (ant. left) and to the BROWN/GREY wire at the position nr. 3 located in the 18 way connector, on the coming out of the ABI central, behind the glove compartment, passenger's side.

**BOOT SWITCH** Connect to the wire located at the position nr. 14, in the 20 way white connector placed in the upper part of the fuse box.