



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

FIAT

MOD.

BRAVO*

YEAR

01 →

PETROL
DIESEL



* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the support of the servobrake in the engine compartment.

CENTRAL UNIT

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ 30: connect to the 4 mm² RED wire located in the 2 way white connector in the fuse box.
- 31: connect directly to the car body.

IGNITION WIRE

+ 15/54: connect to the 1,5 mm² ORANGE wire located in the wiring harness and coming out of the ignition key, alternatively to the 1mm² BLUE/RED wire located in the multiway connector in the fuse box.

DIRECTION INDICATORS

Connect to the LIGHT BLUE and LIGHT BLUE/BLACK wires in the 4 way white connector on the original blinker push button.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the VIOLET/YELLOW wire at the position nr. 8, in the 20 way white connector on the ABI central located behind the glove compartment, passenger's side.

Front window, passenger's side:

cut the VIOLET/WHITE wire at the position nr. 9, in the 20 way white connector on the ABI central located behind the glove compartment, passenger's side.

ACTIVAT./DEACTIVATION CONTROLS

Connections antitheft/vehicle

Art.3800

YELLOW/BLACK

Vehicle

Pos. nr.1

Position

8 way connector

GREY/BLACK

Positive

VIOLET

Positive

ORANGE

Positive

VIOLET/WHITE

Positive

ORANGE/WHITE

Positive

The 8 way connector of the radio set is located in the front roof lamp.

IMMOBILISATION POINT

Fuel pump

Cut the BROWN/WHITE wire located in the white connector of the right lower part of the fuse box.

STARTER

+50: Cut the wire located at the position marked "+50" in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, driver's side.

DOORS SWITCH

Connect to the BROWN/BLACK wire at the position nr. 2 (ant. left) and to the BROWN/GREY wire at the position nr. 3 located in the 18 way connector, on the coming out of the ABI central, behind the glove compartment, passenger's side.

BOOT SWITCH

Connect to the BLACK/VIOLET wire directly on the coming out of the connector of the rear boot lamp.