



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE	FIAT	MOD.	BRAVO	YEAR	97 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens in the engine compartment behind the headlamp on the drivers side, near the battery.								
<b>POWER SUPPLY</b>	<b>+ 30:</b> connect to the 4 mm <sup>2</sup> RED wire located in the 2 way white connector in the fuse box. <b>- 31:</b> connect to the general supply wiring located behind the left lateral bulkhead, drivers side.								
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the 1,5 mm <sup>2</sup> ORANGE wire located in the wiring harness and coming out of the ignition key, alternatively to the 1mm <sup>2</sup> BLUE/RED wire located in the multiway connector in the fuse box.								
<b>DIRECTION INDICATORS</b>	Connect to the LIGHT BLUE wires in the 12 way connector down on the right of the fuse box and to the LIGHT BLUE/WHITE wire in the 14 way white connector on the right of the fuse box.								
<b>ELECTRIC WINDOWS</b>	<b>Positive control signal</b> <b>Front window, driver's side:</b> cut the WHITE/RED wire coming out of the relevant original window switch. <b>Front window, passenger's side:</b> cut the RED/GREEN wire coming out of the relevant original window switch.								
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal</b> Connect to the 0,75 mm <sup>2</sup> WHITE wire (lock) and BLUE wire (unlock) located in the bundle of cables coming out of the drivers side door, at the rear of the fuse box.								
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the 1,5 mm <sup>2</sup> BROWN/WHITE wire located in the white connector of the right lower part of the fuse box.								
<b>BONNET SWITCH</b>	Install an additional switch on the front headlamp support plate, near the rubber grommet of the boot.								
<b>DOORS SWITCH</b>	Connect to the 1 mm <sup>2</sup> WHITE/RED wire located near the core hitch of the drivers side door.								
<b>BOOT SWITCH</b>	Connect to the 1 mm <sup>2</sup> BLACK/VIOLET wire of the switch original line.								