



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	FIAT	MOD.	MAREA	YEAR	97 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment, on the shock absorber, passengers side. To pass the cables open the plastic bulkhead under the windshield wiper and use the original rubber provided of two holes whom one is free. You will find it near the fuse box.								
POWER SUPPLY	+ 30: connect to the 3 mm ² RED wire located in the 1 way black connector, in the upper right part of the fuse box. - 31: connect to the 2 mm ² BROWN wire located in the ground point behind the left lateral bulkhead, drivers side.								
IGNITION WIRE	+ 15/54: connect to the 3 mm ² ORANGE wire located in the wiring harness and coming out of the 4 way white connector of the ignition key.								
DIRECTION INDICATORS	Connect to the 1,5 mm ² BLUE and BLUE/BLACK wires located in the wiring harness and coming out of the multiway white connector in the fuse box, the first in the upper front part of the fuse box.								
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the 2 mm ² WHITE/RED wire. Front window, passenger's side: cut the 2 mm ² RED/GREEN wire. Connections are made directly in the wiring harness coming out of the original switches.								
CENTRAL DOORS LOCKING	Negative control signal Connect to the 1,5 mm ² BLUE wire (lock) and WHITE wire (unlock) located in the wiring harness coming out of the rubber grommet of the front door, drivers side.								
IMMOBILISATION POINT 1	Fuel pump Cut the 1,5 mm ² BROWN/WHITE wire located in the multiway white connector, the first on the left of the fuse box.								
IMMOBILISATION POINT 2	+15 general cut the 3 mm ² ORANGE wire located in the wiring harness and coming out of the 3 way white connector of the ignition key.								
BONNET SWITCH	Install an additional switch on the front headlamp support plate, near the original bonnet stop rubber.								
DOORS SWITCH	Connect to the 1 mm ² WHITE/BLUE wire located in the wiring harness of the 3 way grey connector and coming out of the courtesy lamp.								
BOOT SWITCH	Connect to the 1 mm ² WHITE/RED wire located in the wiring harness of the 2 way grey connector that comes out of the boots interior lamp.								