



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

FIAT

MOD.

PUNTO* JTD

YEAR.

01 →

PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment near the support of the battery. Pass the cables through the original rubber sleeve near the brake fluid reservoir.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+ 30: connect to the 6 mm² WHITE/RED wire located in the multiway connector in the fuse box.
- 31: connect with a ring terminal directly to the car body.

IGNITION WIRE

+ 15/54: connect to the 2 mm² ORANGE wire located in the connector coming out of the ignition key.

DIRECTION INDICATORS

Connect to the 1 mm² PINK and PINK/WHITE wires in the 40 way black connector located in the front part of the fuse box.

ELECTRIC WINDOWS

Controls with mixed polarity

Front window, driver's side:

cut the 2,5 mm² WHITE/RED and VIOLET/YELLOW wire.

Front window, passenger's side:

cut the 2,5 mm² VIOLET/BLACK wire.

These connections should be effected in the wiring harnesses coming out of the original switches of the windows closing.

ACTIVAT./DEACTIVATION CONTROLS

Connections for art. 3800

To make this connection refer to the **diagram nr. 104**.

IMMOBILISATION POINT

Gasoil pump

Cut the 2,5 mm² VIOLET/YELLOW wire located in the wiring harness, at the position nr.32, coming out of the 32 way black connector, in the front part of the fuse box.

STARTER

+50: Cut the WHITE/BLACK wire located in the wiring harness coming out of the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate.

DOORS SWITCH

For the vehicles with 2 doors: connect to the 1 mm² LIGHT BLUE wire (BLUE/YELLOW wire in the version with 4 doors) in the 40 way black connector located in the front part of the fuse box.

BOOT SWITCH

Connect to the wire located in the wiring harness coming out of the connector of the boot lamp.



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°104

Diagram for the interfacing of art. 3800 on
FIAT PUNTO year 2001

Art. 3800

The GREY and YELLOW wires
are located in the wiring harness
coming out of the driver's side
door.

