



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	FIAT	MOD.	SCUDO	YEAR	02 →	PETROL	<input type="checkbox"/>	DIESEL	<input checked="" type="checkbox"/>
ALARM/SIREN POSITION									
CENTRAL UNIT POSITION									
POWER SUPPLY									
IGNITION WIRE									
DIRECTION INDICATORS									
ELECTRIC WINDOWS									
CENTRAL DOORS LOCKING									
IMMOBILISATION POINT									
STARTER									
BONNET SWITCH									
DOORS SWITCH									
BOOT SWITCH									



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°165

Diagram to make the central locking on
FIAT SCUDO year 2002

(for 3100-3900 series antithefts: use the VIOLET/WHITE and ORANGE/WHITE wires)

(for 7900 serie antithefts: use the VIOLET/ORANGE wires)

