



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **FIAT** MOD. **SCUDO** YEAR **98** → PETROL
DIESEL

ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment between the battery and the driver's side headlamp. Pass the cables through the original hole on the panel of the engine compartment, above the shock absorber, passenger's side.
POWER SUPPLY	+ 30: connect to the general supply wiring of the fuse box located in a multiway connector. - 31: connect with a ring terminal to one of the terminals coming out of the original power supply behind the left lateral panel on the driver's side.
IGNITION WIRE	+ 15/54: connect to the 1,5 mm ² WHITE wire located in the wiring harness coming out of the first connector on the left of the fuse box.
DIRECTION INDICATORS	Connect to the GREEN wire marked nr. 233 and to the GREEN wire marked nr. 234 located in the wiring harness coming out of the multiway black connector of the lights switch.
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the WHITE wire marked nr. 6050 located in the wiring harness coming out of the windows central unit under the dashboard, driver's side. Front window, passenger's side: cut the YELLOW wire marked nr. 609 located in the wiring harness coming out of the windows central unit.
CENTRAL DOORS LOCKING	Negative control signal Connect to the GREEN wire marked nr. 6290 (unlock) and to the GREEN wire marked nr. 6291 (lock) of the wiring harness located behind the driver's side lateral panel.
IMMOBILISATION POINT	Gasoil pump Cut the WHITE wire located in the wiring harness coming out of the inertial switch in the engine compartment, passenger's side.
STARTER	+50: Cut the RED wire located in wiring harness coming out of the 2 way connector, under the superior steering wheel cover box.
BONNET SWITCH	Install an additional switch on the headlamp support plate, near the left lateral headlamp.
DOORS SWITCH	Connect to the GREEN wire marked nr. 300 located in the wiring harness coming out of the 12 way brown connector, near the windows central unit.