



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

FORD

MOD.

FIESTA *

YEAR

02 →

PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens behind the driver's side headlamp. Pass the cables using the rubber sleeve located on the bulkhead that divides the engine compartment and the passenger's compartment.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the dashboard, driver's side.

POWER SUPPLY

+30: connect to a positive that supply the fuse box.
-31: connect to an original ground terminal located on the left, under the dashboard, driver's side.

IGNITION WIRE

+15/54: connect to the WHITE/GREEN wire, at the position nr.1, in the black connector above the brake pedal.

DIRECTION INDICATORS

Connect to the BLUE wire, at the position nr.7, and to the BLUE/RED wire at the position nr.6, in the light blue connector in the central, under the steering column, driver's side.

ELECTRIC WINDOWS

Positive control signal
Front window driver's side:
cut the WHITE wire in the 7 way black connector, in the original push buttons panel.
Front windows passenger's side:
cut the WHITE/VIOLET wire in the wiring harness coming out of the driver's side door.

ACTIVAT./DEACTIVATION CONTROLS

Connections antitheft/vehicle

Art. 3800	Vehicle	Position
YELLOW/BLACK	WHITE/RED	Pos. nr. 4 in the green connector
GREY/BLACK	YELLOW/RED	Pos. nr. 3 in the green connector
VIOLET	BLACK/RED	Pos. nr. 9 in the green connector
ORANGE	BLACK/GREEN	Pos. nr.12 in the dark grey connector
VIOLET/WHITE	ground	car body
ORANGE/WHITE	positive	supply in the fuse box

The above green and grey connectors are located on the coming out of the central doors locking unit located under the steering column.
Refer to the 'C' diagram of the dedicated installations manual inside the kit of the antitheft.

IMMOBILISATION POINT

Inertial switch
Cut the GREEN/ORANGE wire directly in the wiring harness coming out of the inertial switch located behind the passenger's side glove compartment.

STARTER

+50: Cut the GREY/BLACK wire, at the position nr.7, in the 7 way black connector, in the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate, driver's side.

DOORS AND BOOT SWITCHES

Connect to the BLACK/BLUE wire, at the position nr.3 in the dark grey connector, in the central under the steering column, driver's side.