



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	FORD	MOD.	FOCUS*	YEAR.	02 →	PETROL <input type="checkbox"/>	DIESEL <input checked="" type="checkbox"/>
------	-------------	------	---------------	-------	-------------	---------------------------------	--

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION Position the compact alarms and the sirens on the bulkhead that divides the engine compartment and the passenger's compartment.

CENTRAL UNIT POSITION Position the modular systems and the modules behind the fuse box, under the dashboard, passenger's side.

POWER SUPPLY
+ 30: connect to the 6 mm² RED wire located in a multiway connector in the fuse box.
- 31: connect to one of the ground terminals behind the left lateral bulkhead, driver's side.

IGNITION WIRE + 15/54: connect to the GREY/ORANGE wire coming out of the ignition key.

DIRECTION INDICATORS Connect to the BLUE wire, at the position nr. 3 and to the BLUE wire, at the position nr. 4 located in the light blue connector, on the central locking unit, behind the passenger's side glove compartment.

ELECTRIC WINDOWS The windows locking is obtained from the original transmitter only.

ACTIVAT./DEACTIVATION CONTROLS

Art. 3800	Vehicle	Position
YELLOW/BLACK	YELLOW/BLACK	pos. nr. 3, green connector
GREY/BLACK	BLACK/WHITE	pos. nr. 5, green connector
VIOLET	BLACK/GREEN	pos. nr.11, green connector
ORANGE	positive	supply in the fuse box
VIOLET/WHITE	ground	car body
ORANGE/WHITE	positive	supply in the fuse box

The green connector is located on the GEM central behind the driver's side glove compartment.
Note: Follow the B diagram of the dedicated installations manual located in the kit of the antitheft.

IMMOBILISATION POINT **Gasoil pump**
Cut the GREEN/BLACK wire located at the position nr. 3, in the 8 way white connector, fitted on the fuses box.

STARTER +50: Cut the 2,5 mm² GREY wire located in a multiway connector, in the fuse box.

BONNET SWITCH Install an additional switch on the headlamp support plate, driver's side.

DOORS SWITCH Connect to the BLACK/YELLOW wire in the white connector for the driver's side front door, to the BLACK/BLUE wire in the white connector for the passenger's side front door, to the BLACK/ORANGE wire in the green connector for the driver's side rear door and to the BLACK/GREEN wire in the grey connector for the passenger's side rear door. The connectors are located on the central locking, behind the passenger's side glove compartment.
(Temporized) ceiling lamp control
Connect to the BLACK/BLUE wire at the position nr. 3, in the dark grey connector, coming out of the central of the central locking unit located behind the passenger's side glove compartment.

BOOT SWITCH Connect to the BLACK/YELLOW wire, in the brown connector coming out of the central locking unit located behind the passenger's side glove compartment.