



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	FORD	MOD.	KA	YEAR	96 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
ALARM/SIREN POSITION									
POWER SUPPLY									
IGNITION WIRE									
DIRECTION INDICATORS									
ELECTRIC WINDOWS									
CENTRAL DOORS LOCKING									
IMMOBILISATION POINT									
STARTER									
BONNET SWITCH									
DOORS SWITCH									
BOOT SWITCH									