



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

FORD

MOD.

MONDEO

YEAR.

02 →

PETROL

DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the passenger's side wheelhouse.

CENTRAL UNIT POSITION

The modular systems and the modules should be positioned under the dashboard, driver's side.

POWER SUPPLY

+ **30**: Connect to the ORANGE/WHITE wire located in the wiring harness coming out of the blue connector of the central locking unit placed behind the passenger's side glove compartment.

- **31**: Connect to the BLACK wire located in the wiring harness coming out of the grey connector of the central locking unit, placed behind the passenger's side glove compartment.

IGNITION WIRE

+ **15/54**: Connect to the 2 mm² GREEN/RED wire located in the wiring harness coming out of the 2 way grey connector, in the fuse box.

DIRECTION INDICATORS

Connect to the BLUE wire in the wiring harness coming out of the grey connector and to the BLUE/RED wire coming out of the green connector. The connectors are located on the central locking unit placed behind the passenger's side glove compartment.

ELECTRIC WINDOWS

Comfort locking

To make the windows locking it is necessary to keep pressed the button of the original radiocontrol.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the BLACK/ORANGE wire, at the position nr. 19, in the 23 way grey connector (lock), and to the BLACK/GREEN wire, at the position nr. 17 in the green connector (unlock). The connectors are located on the coming out of the central doors locking unit placed behind the glove compartment, passenger's side.

IMMOBILISATION POINT

Inertial switch

Cut the GREEN/ORANGE wire located in the wiring harness coming out of the connector of the inertial switch placed behind the driver's side lateral bulkhead.

STARTER

+ **50**: Cut the GREY/WHITE wire located in the wiring harness coming out of the 14 way green connector, on the connector's holder plate, under the driver's side dashboard.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, driver's side.

DOORS SWITCH

Connect to the RED/BLACK wire (front left) at the position nr.22 and to the GREEN/BLACK wire (front right) at the position nr.21, on the coming out of the white connector; to the BLACK/ORANGE wire (rear right) at the position nr.18, in the grey connector and to the ORANGE/BLACK wire (rear left) at the position nr.15, in the green connector.

The connectors are located on the coming out of the central locking unit placed behind the passenger's side glove compartment. It is suggested to separate the lines with 4 diodes.

BOOT SWITCH

Connect directly to the wire coming out from the boot lamp. It is necessary to install a diode.