



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	HYUNDAI	MOD.	ATOS	YEAR	98 →	PETROL	<input checked="" type="checkbox"/>
						DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, passenger's side.						
<b>POWER SUPPLY</b>	<b>+ 30:</b> connect to the general supply wiring in the general power supply connector of the fuse box. <b>- 31:</b> connect with a terminal to one of the original bolts located behind the left lateral panel, driver's side.						
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the 1,5 mm <sup>2</sup> YELLOW/RED wire located in the wiring harness coming out of the 8 way black connector of the fuel pump relay located under the glassholder console before the speed change lever.						
<b>DIRECTION INDICATORS</b>	Connect to the 1 mm <sup>2</sup> GREEN/LIGHT BLUE and GREEN/YELLOW wires located in the wiring harness coming out of the 20 way white connector located under the dashboard, driver's side.						
<b>ELECTRIC WINDOWS</b>	<b>Positive control signal</b> <b>Front window, driver's side:</b> cut the 1 mm <sup>2</sup> BROWN/RED wire located in the wiring harness coming out of the 7 way transparent connector directly connected to the control switch inside the driver's side door. <b>Front window, passenger's side:</b> cut the 1,5 mm <sup>2</sup> BLUE/WHITE wire located in the wiring harness of the 21 way white/yellow connector directly coming out of the driver's side door behind the left lateral panel.						
<b>CENTRAL DOORS LOCKING</b>	<b>Additional motor</b> it is necessary to install an additional motor in the driver's side door as it is unprovided with actuating device.						
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the 1,5 mm <sup>2</sup> YELLOW/RED wire located in the wiring harness coming out of the 8 way black connector of the fuel pump relay located under the glassholder console before the speed change lever.						
<b>STARTER</b>	<b>+50:</b> Cut the 2,5 mm <sup>2</sup> BLACK/YELLOW wire located in the wiring harness coming out of the 6 way black/blue connector under the steering column.						
<b>BONNET SWITCH</b>	Install an additional switch on the headlamp support plate, in correspondence with the left lateral lamp, passenger's side.						
<b>DOORS SWITCH</b>	Connect to the 0,75 mm <sup>2</sup> BLUE/BLACK wire located in the wiring harness coming out of the front left sill cover and going towards the rear of the vehicle.						