



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

**HYUNDAI**

MOD.

**GALLOPER**

YEAR

**98** →

PETROL   
DIESEL

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the wheelhouse, passenger's side. Pass the cables through the original rubber sleeve on the right of the servobrake.

#### POWER SUPPLY

**+ 30:** connect to the general supply wiring located in the multiway connector at the entrance of the fuse box.  
**- 31:** connect with a ring terminal to one of the terminals coming out of the general power supply behind the left lateral panel, driver's side.

#### IGNITION WIRE

**+ 15/54:** connect to the 2 mm<sup>2</sup> BLACK/WHITE wire in the wiring harness coming out of the 6 way connector, near the steering column.

#### DIRECTION INDICATORS

Connect to the 1 mm<sup>2</sup> GREEN/YELLOW and GREEN/LIGHT BLUE wires located in the wiring harness coming out of the 21 way connector near the steering column.

#### ELECTRIC WINDOWS

##### Positive control signal

##### Front window, driver's side:

cut the BLUE/WHITE wire directly in the wiring harness coming out of the driver's side door switch.

##### Front window, passenger's side:

cut the LIGHT BLUE/GREEN wire located in the wiring harness coming out of the core hitch of the driver's side door.

#### CENTRAL DOORS LOCKING

##### Additional motor

It is necessary to install a 2 wires motor (Art.1060) as the driver's side door is not provided with an actuating device.

#### IMMOBILISATION POINT

##### Fuel pump

Cut the BLACK/WHITE wire located in the wiring harness coming out of the 6 way connector, in the electrovalve unit, in the engine compartment.

#### STARTER

**+50:** Cut the 2 mm<sup>2</sup> BLACK/YELLOW wire located in the wiring harness coming out of the 6 way connector under the steering column.

#### BONNET SWITCH

Install an additional switch on the headlamp support plate, in correspondence with the left lateral lamp.

#### DOORS SWITCH

Connect to the RED/GREEN wire located in the wiring harness coming out of the 16 way white connector and going out of the white central unit, under the fuse box in the lower part of the dashboard, driver's side.

#### BOOT SWITCH

It is necessary to install an additional switch as the vehicle has no connection point.