



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE	MOD.	YEAR	PETROL DIESEL
<b>LANCIA</b>	<b>LYBRA</b>	<b>99</b> →	<input checked="" type="checkbox"/> <input type="checkbox"/>

  

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens on the left in the engine compartment.
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the left side of the dashboard, driver's side.
<b>POWER SUPPLY</b>	+ 30: connect to the 4 mm <sup>2</sup> RED wire located at the entrance of the fuse box. - 31: connect with a ring terminal directly to the car body.
<b>IGNITION WIRE</b>	+ 15/54: connect to the BLUE wire at the position nr. 7 of the 19 way white connector.
<b>DIRECTION INDICATORS</b>	Connect to the PINK/WHITE wire in the 14 way connector and to the PINK wire in the 12 way connector located in the front part of the fuse box.
<b>ELECTRIC WINDOWS</b>	<b>Negative control signal</b> To obtain the windows closing it is necessary to connect to the BLUE/WHITE wire located at the position nr. 18 in the 18 way white connector coming out of the multiservice central unit located under the sill cover, passenger's side, and extend the command to 24s.
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal</b> Connect to the GREEN/WHITE wire at the position nr. 16 (unlock) and to the VIOLET/YELLOW wire at the position nr. 15 (lock) located in the 18 way white connector coming out of the multiservice central unit, under the sill cover, passenger's side.
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> Cut the 2 mm <sup>2</sup> VIOLET/YELLOW wire located in the 14 way connector in the front part of the fuse box.
<b>STARTER</b>	+50: Cut the RED/BLACK wire located in the wiring harness coming out of the connector of the ignition key.
<b>BONNET SWITCH</b>	Install an additional switch on the headlamp support plate.
<b>DOORS SWITCH</b>	For the front doors: connect to the 0,5 mm <sup>2</sup> BROWN/GREEN and WHITE/RED wires located in the 18 way connector. For the rear doors: connect to the 0,5 mm <sup>2</sup> GREEN and GREEN/WHITE wires located in the 16 way black connector.
<b>BOOT SWITCH</b>	Connect to the 0,5 mm <sup>2</sup> GREY/BLACK wire in the 16 way black connector.