



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MOD.	YEAR.	PETROL	DIESEL
MINI	ONE	02 →	<input checked="" type="checkbox"/>	<input type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens in the windshield wiper compartment, passenger's side.			
CENTRAL UNIT POSITION	The modular systems and the modules should be positioned behind the glove compartment, passenger's side.			
POWER SUPPLY	+30: connect to the RED/YELLOW wire in the green connector, behind the passenger's side sill cover. - 31: connect to a ground terminal located behind the left side bulkhead.			
IGNITION WIRE	+15/54: connect to the WHITE/BLUE wire, in the green connector, behind the passenger's side sill cover.			
DIRECTION INDICATORS	Connect to the wires: LIGHT BLUE/GREEN at the position nr. 16, LIGHT BLUE/YELLOW at the position nr. 9, LIGHT BLUE/GREEN at the position nr. 18, LIGHT BLUE/BROWN at the position nr. 5, LIGHT BLUE/YELLOW at the position nr. 13, LIGHT BLUE/BROWN at the position nr. 8, in the 54 way white connector, in the central unit behind the passenger's side sill cover. Separate the lines with diodes.			
ELECTRIC WINDOWS	Negative control signal The locking of the windows is obtained timing at 24s. the BLUE/RED wire at the position nr.21, in the 54 way black connector, on the central unit behind the passenger's side sill cover.			
CENTRAL DOORS LOCKING	Negative control signal Connect to the BLUE/RED wire, at the position nr.21 of locking of the alarm and to the WHITE/BLACK wire, at the position nr. 3, in the 54 way black connector, in the main central, behind the passenger's side sill cover.			
IMMOBILISATION POINT	Fuel pump Cut the WHITE/LIGHT BLUE wire, at the position nr. 3, in the 12 way white connector placed in the rear part of the fuse box, behind the driver's side lateral bulkhead.			
STARTER	+50: Cut the BLACK/LIGHT BLUE wire, at the position nr. 8 of the connector coming out of the ignition key.			
BONNET SWITCH	Connect to the VIOLET/GREEN wire, at the position nr. 40, in the 54 way connector, in the central unit behind the passenger's side sill cover.			
DOORS SWITCH	Connect to the BROWN/GREY/YELLOW wire, at the position nr. 22 and to the BROWN/GREY/YELLOW wire, at the position nr. 42, in the 54 way black connector, in the central unit behind the passenger's side sill cover.			
BOOT SWITCH	Connect to the GREY/BROWN wire, at the position nr. 24, in the 54 way black connector, in the central unit behind the passenger's side sill cover.			