



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MAZDA	MOD.	DEMIO	YEAR	99 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment, driver's side, on the support of the shock absorber.								
CENTRAL UNIT POSITION	The modular systems and the modules should be positioned under the dashboard, driver's side. Pass the cables through the original rubber sleeve of the odometer cable.								
POWER SUPPLY	+ 30: connect to the general supply wiring located at the entrance of the fuse box. - 31: connect with a ring terminal directly to the car body.								
IGNITION WIRE	+ 15/54: connect to the 1 mm ² BLUE/GREEN wire located in the wiring harness behind the sill cover, driver's side.								
DIRECTION INDICATORS	Connect to the 1 mm ² GREEN/WHITE and BLACK/GREEN wires located in the wiring harness behind the sill cover, driver's side.								
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the 2 mm ² RED wire located in the wiring harness coming out of the serial switch in the driver's side door. Front window, passenger's side: cut the 2 mm ² YELLOW wire located in the wiring harness coming out of the driver's side door.								
CENTRAL DOORS LOCKING	Negative control signal Cut the 1 mm ² GREEN/YELLOW and GREEN/RED wires located in the wiring harness coming out of the central doors locking unit on the left bulkhead under the dashboard, driver's side. Make reference to the diagram nr. 59 .								
IMMOBILISATION POINT	Fuel pump Cut the 1,5 mm ² GREEN/YELLOW wire located in the wiring harness behind the sill cover, driver's side.								
STARTER	+ 50: Cut the 3 mm ² BLACK/WHITE wire located in the wiring harness coming out of the connector of the ignition key.								
BONNET SWITCH	Install an additional switch on the headlamp support plate, near the left lateral headlamp.								
DOORS SWITCH	Connect to the 1 mm ² BLUE/RED wire located in the wiring harness behind the sill cover, driver's side.								
BOOT SWITCH	Connect to the 1 mm ² BLUE/RED wire located in the wiring harness coming out of the boot lamp.								



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N° 59

Diagram to make the locking and the opening of the doors on
MAZDA DEMIO
(for antitheft with 6 wires locking)

