



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MAZDA	MOD.	MPV	YEAR	96 →	PETROL	<input type="checkbox"/>	DIESEL	<input checked="" type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens on the support of the shock absorber, driver's side. Position the modular systems and the modules under the mat of the right footrest, passenger's side.								
POWER SUPPLY	+ 30: connect to the 4 mm ² RED wire located in a multivay connector at the entrance of the fuse box. - 31: connect with a cable terminal directly to the car body. Check the ground connection.								
IGNITION WIRE	+ 15/54: connect to the 1,5 mm ² BLACK/YELLOW wire with SILVER references located in the wiring harness coming out of the 21 way white connector in the fuse box, under the driver's side dashboard.								
DIRECTION INDICATORS	Connect to the GREEN/WHITE wire with SILVER references and to the GREEN/BLACK wire with SILVER references located in the wiring harness coming out of the 21 way white connector, in the fuse box, under the driver's side dashboard.								
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the RED/BLACK wire with SILVER references directly in the wiring harness inside the driver's side door. Front window, passenger's side: cut the RED/WHITE wire with SILVER references. Rear window, driver's side: cut the WHITE/GREEN wire with SILVER references. Rear window, passenger's side: cut the RED/YELLOW wire with SILVER references.								
CENTRAL DOORS LOCKING	Additional motor It is necessary to install an additional motor inside the driver's side door as it is not provided with an actuating device.								
IMMOBILISATION POINT 1	Gasoil pump Cut the 1,5 mm ² BLACK/YELLOW wire located in the wiring harness coming out of the 6 way green connector, behind the fuse box.								
IMMOBILISATION POINT 2	Electronic central unit Cut the 1,5 mm ² ORANGE wire with SILVER references located in the wiring harness coming out of the connector of the central unit under the right footrest, passenger's side.								
STARTER	+ 50: Cut the 2 mm ² BLACK/YELLOW wire located in the wiring harness coming out directly of the connector of the ignition key.								
BONNET SWITCH	Install an additional switch on the headlamp support plate, driver's side.								
DOORS AND BOOT SWITCH	Connect to the 1 mm ² PINK wire with SILVER references located in the wiring harness coming out of the 16 way green connector, in the fuse box.								