



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MAZDA	MOD.	MX-5	YEAR	97 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment on the support of the shock absorber, passenger's side. Pass the cables through the original rubber core hitch located near the servobrake in the engine compartment, driver's side.								
POWER SUPPLY	+ 30: connect to the 2 mm ² RED wire located in the wiring harness coming out of the multiway general power supply connector of the fuse box. - 31: connect to the original ground pin behind the left lateral panel, driver's side.								
IGNITION WIRE	+ 15/54: connect to the 1,5 mm ² BLACK/YELLOW wire located in the wiring harness coming out of the 19 way white connector, under the steering column.								
DIRECTION INDICATORS	Connect to the 1,5 mm ² GREEN/WHITE and GREEN/BLACK wires located in the wiring harness coming out of the 19 way white connector, under the steering column.								
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the 2 mm ² RED/BLACK wire. Front window, passenger's side: cut the 2 mm ² GREEN/WHITE wire. These wires are in the wiring harness coming out of the 6 way white connector located under the central tunnel.								
CENTRAL DOORS LOCKING	It is necessary to install an additional motor inside the driver's side door as it is not provided with an actuating device.								
IMMOBILISATION POINT 1	Fuel pump Cut the 1,5 mm ² BLACK/WHITE wire located in the wiring harness coming out of the 15 A fuse in the fuse box, under the left dashboard, driver's side.								
IMMOBILISATION POINT 2	Electronic ignition cut Cut the 2 mm ² WHITE/RED wire located in the wiring harness coming out of the injection central unit, under the passenger's side footrest.								
STARTER	+ 50: Cut the 2,5 mm ² BLACK/BLUE wire located in the wiring harness coming out of the connector of the ignition key.								
BONNET SWITCH	Install an additional switch on the headlamp support plate, near the left lateral headlamp.								
DOORS SWITCH	Connect to the 1mm ² RED/WHITE wire located in the wiring harness coming out of the driver's side connector.								