



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **MITSUBISHI** MOD. **3000 GT** YEAR **98** → PETROL DIESEL

ALARM/SIREN POSITION	Position the compact alarms and the sirens in the engine compartment, on the plate near the shock absorber, passengers side.
POWER SUPPLY	+ 30: connect to the 4 mm ² RED wire located in the wiring harness coming out of the 2 way connector disposed at the entrance of the fuse box. - 31: connect with a ring terminal directly to the car body.
CENTRAL UNIT POSITION	Position the modular systems and the modules in the front part of the central tunnel.
IGNITION WIRE	+ 15/54: connect to the 1,5 mm ² LIGHT BLUE wire located in the multiway connector (the greatest) in the fuse box.
DIRECTION INDICATORS	Connect to the GREEN/LIGHT BLUE wires located in the 16 way black connector near the steering column.
ELECTRIC WINDOWS	Positive control signal Front window, drivers side Cut the GREEN/RED wire directly on the output of the relevant control switch. Front window, passengers side Cut the BROWN/YELLOW wire coming out of the doors connector, drivers side.
CENTRAL DOORS LOCKING	Negative control signal Connect to the BROWN/BLUE wire with SILVER reference (unlock) and BROWN/WHITE with SILVER reference (lock) located in the wiring harness coming out of the connector of the central door locking unit under the dashboard, drivers side
IMMOBILISATION POINT 1	Fuel pump Cut the WHITE/BLACK wire located behind the inner part of the central tunnel, passengers side.
IMMOBILISATION POINT 2	Electronic ignition cut Cut the BLACK/WHITE wire with SILVER reference located in the wiring harness coming out of the electronic ignition unit under the prearrangement of the car radio.
STARTER	+50: Cut the 2 mm ² BLACK/RED wire located in the wiring harness coming out of the connector of the ignition key.
DOORS SWITCH	Connect to the RED/GREEN wire with SILVER reference located in the wiring harness coming out of the central door locking unit.
BOOT AND BONNET SWITCH	Connect to the BLUE/WHITE wires with SILVER reference and BLUE/BLACK with SILVER reference located in the wiring harness coming out of the central door locking unit.