



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

MITSUBISHI

MOD.

CARISMA*

YEAR.

01 →

PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION

Position the compact alarms and the sirens on the servobrake support, in the engine compartment.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the driver's side dashboard.

POWER SUPPLY

+ **30**: connect to the WHITE wire located in the wiring harness coming out of the central doors locking unit placed under the central console.
- **31**: connect directly to the car body.

IGNITION WIRE

+ **15/54**: connect to the BLUE wire in the wiring harness coming out of the connector of the central doors locking unit located under the central console.

DIRECTION INDICATORS

Connect to the GREEN/RED and GREEN/BLACK wires located in the wiring harness coming out of the connector of the central doors locking unit placed under the central console.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

Cut the GREEN/RED wire located in the wiring harness coming out of the original switch.

Front window, passenger's side:

Cut the RED/YELLOW wire located in the wiring harness coming out of the driver's side door.

Rear window, driver's side:

Cut the YELLOW/RED wire with SILVER reference located in the wiring harness coming out of the driver's side door.

Rear window, passenger's side:

Cut the WHITE/RED wire with SILVER reference located in the wiring harness coming out of the driver's side door.

ACTIVAT./DEACTIVATION CONTROLS

Connections antitheft/vehicle

38XX

YELLOW/BLACK

Vehicle

BLUE/WHITE (motor)

Position

central doors locking unit

GREY/BLACK

BLUE/BLACK (motor)

central doors locking unit

VIOLET

GREEN/RED (BLK)

central doors locking unit

ORANGE

ground

car body

VIOLET/WHITE

ground

car body

ORANGE/WHITE

ground

car body

The connection must be done in the wiring harness coming out of the connector of the central doors locking unit located under the central console.

IMMOBILISATION POINT

Central locking

Cut the BLACK/WHITE wire located in the wiring harness coming out of the connector of the central unit, behind the driver's side loudspeaker.

STARTER

+ **50**: Cut the BLACK/YELLOW wire located in the wiring harness coming out of the connector of the ignition key.

BONNET SWITCH

Install an additional switch on the front headlamp support plate, driver's side.

DOORS SWITCH

Connect to the RED/GREEN wire with SILVER references located in the wiring harness under the driver's side sill cover.

BOOT SWITCH

Connect to the RED/GREEN wire with BLACK reference located in the wiring harness coming out of the boot lamp.