



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	HONDA	MOD.	LOGO	YEAR	98 →	PETROL	<input checked="" type="checkbox"/>	DIESEL	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>									
<b>CENTRAL UNIT POSITION</b>									
<b>POWER SUPPLY</b>									
<b>IGNITION WIRE</b>									
<b>DIRECTION INDICATORS</b>									
<b>ELECTRIC WINDOWS</b>									
<b>CENTRAL DOORS LOCKING</b>									
<b>IMMOBILISATION POINT</b>									
<b>STARTER</b>									
<b>BONNET SWITCH</b>									
<b>DOORS SWITCH</b>									
<b>BOOT SWITCH</b>									



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

FITTING DIAGRAM N°126

Diagram to make the locking and the opening of the doors on  
**HONDA CR-V, HR-V, LOGO**  
(for antitheft with 6 wires locking, with serie Bridge using Art. 1044)

