



SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **JEEP** MOD. **GRAND CHEROKEE*** YEAR. **02** → PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION	Position the compact alarms and the sirens, on the passenger's side wheelhouse, in the engine compartment.
CENTRAL UNIT POSITION	Position the modular system and the modules behind the fuse box, under the dashboard, passenger's side.
POWER SUPPLY	+30: connect to the RED/WHITE wire located in the fuse box. - 31: connect to a ground terminal located behind the driver's side bulkhead.
IGNITION WIRE	+15/54: connect to the 4 mm ² BLUE wire in the wiring harness coming out of the connector of the ignition key.
DIRECTION INDICATORS	Connect to the BROWN/RED and GREEN/RED wires in the bundle of cables behind the driver's side sill cover.
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the GREEN wire directly in the wiring harness, inside the driver's side door. Front window, passenger's side: cut the BROWN wire directly in the wiring harness, inside the driver's side door.
ACTIVAT./DEACTIVATION CONTROLS	Connections antitheft/vehicle It is suggested to refer to the fitting diagram nr. 169.
IMMOBILISATION POINT	Gasoil pump Cut the YELLOW/RED wire located in the wiring harness coming out of the 2 way connector placed directly on the clutch pedal.
STARTER	+50: Cut the 4 mm ² YELLOW wire located in the wiring harness coming out of the connector of the ignition key.
BONNET SWITCH	Install an additional switch on the headlamp support plate, driver's side.
DOORS AND BOOT SWITCH	Connect to the YELLOW wire located in the wiring harness coming out of the connector of the lamp, under the driver's side dashboard.

FITTING DIAGRAM NR. 169

Diagram to connect art. 3800 on
JEEP GRAND CHEROKEE year 2002

