





**NB !** This installation diagram must only be used as a guideline for the installation. Equipment delivered with the car varies considerably from model to model and from market to market. Before starting the installation, be sure to check carefully the original diagram from the car manufacturer. DEFA A.S is not liable to compensate for possible damages that may occur due to faulty or insufficient installation manuals.

**NOTE:**  
SIDE DIRECTION INDICATORS ARE NOT CONNECTED!




**REQUIRED:**  
- Central unit rev: E →  
- Diodes (1 X 600535)

Date : 2004.11.08  
Rev : A  
Page: 1 of 3



**HOW TO SYNCHRONISE CAN INTERFACE:**

- 1) INSERT 25A FUSE. => LED WILL START FLASHING
  - 2) TURN ON IGNITION. => LED WILL STOP FLASHING WITHIN 30 SECONDS.
- THE ALARM IS NOW SYNCHRONISED.

 For hardware rev. J and later !  
Programming:  
- PROG NR: 8.2.  
- PROG NR: 15.1.

