



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE **ALFA ROMEO** MOD. **156*** YEAR. **02** → PETROL
DIESEL

* Models with original equipment keyless entry system.

ALARM/SIREN POSITION	Position the compact alarms and the sirens behind the left or right lateral headlamp, it depends on the vehicle version.																								
CENTRAL UNIT POSITION	The modular systems and the modules should be positioned under the dashboard, driver's side.																								
POWER SUPPLY	+30: connect to the general supply wiring at the entrance of the fuse box. -31: connect directly to the car body.																								
IGNITION WIRE	+15/54: connect to the RED/ORANGE wire located in the 20 way white connector in the front part of the fuse box. Alternatively, in the wiring harness located under the sill cover, driver's side.																								
DIRECTION INDICATORS	Connect to the 1 mm ² LIGHT BLUE wire in the 20 way white connector and LIGHT BLUE/BLACK in the 12 way connector. These connectors are located in the front part of the fuse box, under the dashboard, drivers side. Alternatively in the wiring harness under the sill cover, driver's side.																								
ELECTRIC WINDOWS	Positive control signal Front window, driver's side: cut the BROWN/WHITE wire. Front window, passenger's side: cut the VIOLET/WHITE wire. Connections must be done in the wiring harness coming out of the connector of the centrallocated behind the glove compartment, passenger's side. Rear window, driver's side: cut the YELLOW/RED wire. Rear window, passenger's side: cut the LIGHT BLUE/GREEN. Connections must be done in the wiring harness under the sill cover, driver's side.																								
ACTIVAT./DEACTIVATION CONTROLS	<table><thead><tr><th colspan="3">Connections antithefts/vehicle</th></tr><tr><th>Art. 3800</th><th>Vehicle</th><th>Position</th></tr></thead><tbody><tr><td>GREY/BLACK</td><td>free position</td><td>Pin nr.1, 8 way connector</td></tr><tr><td>YELLOW/BLACK</td><td>+30</td><td>in the fuse box</td></tr><tr><td>VIOLET</td><td>+30</td><td>in the fuse box</td></tr><tr><td>ORANGE</td><td>+30</td><td>in the fuse box</td></tr><tr><td>ORANGE/WHITE</td><td>+30</td><td>in the fuse box</td></tr><tr><td>VIOLET/WHITE</td><td>+30</td><td>in the fuse box</td></tr></tbody></table>	Connections antithefts/vehicle			Art. 3800	Vehicle	Position	GREY/BLACK	free position	Pin nr.1, 8 way connector	YELLOW/BLACK	+30	in the fuse box	VIOLET	+30	in the fuse box	ORANGE	+30	in the fuse box	ORANGE/WHITE	+30	in the fuse box	VIOLET/WHITE	+30	in the fuse box
Connections antithefts/vehicle																									
Art. 3800	Vehicle	Position																							
GREY/BLACK	free position	Pin nr.1, 8 way connector																							
YELLOW/BLACK	+30	in the fuse box																							
VIOLET	+30	in the fuse box																							
ORANGE	+30	in the fuse box																							
ORANGE/WHITE	+30	in the fuse box																							
VIOLET/WHITE	+30	in the fuse box																							
IMMOBILISATION POINT 1	Gasoil pump Cut the BLACK/VIOLET wire coming out of the wiring harness of the inertial switch located under the driver's side seat.																								
IMMOBILISATION POINT 2	Cut the ORANGE wire in a connector coming out of the central engine plant located under the dash board, passenger's side.																								
STARTER	+50: Cut the 2 mm ² RED/BLACK wire located in the wiring harness coming out of the connector of the ignition key.																								
BONNET SWITCH	Install an additional switch on the front headlamp support grill, driver's side.																								
DOORS SWITCH	Connect to the WHITE/BLUE wire located in the black connector under the left side of the dashboard near the handle of the bonnet. Alternatively, in the wiring harness under the sill cover, driver's side.																								
BOOT SWITCH	Connect to the 1 mm ² RED wire located in the connector mentioned above; alternatively in the wiring harness located in the sill cover, driver's side.																								