



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

[www.cobra.it](http://www.cobra.it)

MAKE

**DAEWOO**

MOD.

**NEXIA**

YEAR

**98** →

PETROL   
DIESEL

#### ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, near the left lateral headlamp. Position the modular systems and the modules under the dashboard, drivers side.

#### POWER SUPPLY

**+ 30:** connect to the 2,5 mm<sup>2</sup> RED wire located at the rear of the left lateral frame, drivers side.  
**- 31:** connect with an eyelet cable terminal to one of the fastening bolt of the dashboard.

#### DIRECTION INDICATORS

Connect to the 1 mm<sup>2</sup> BLACK and YELLOW wires located in the wiring harness and coming out of the 20 way white connector on the pillar of the drivers side support.

#### ELECTRIC WINDOWS

##### Positive control signal

##### Front window, driver's side:

cut the YELLOW wire directly outgoing from the switch of the window to the inner drivers side door.

##### Front window, passenger's side:

cut the 1,5 mm<sup>2</sup> BLUE/BLACK wire.

##### Rear window, driver's side:

cut the 1,5 mm<sup>2</sup> BLUE/BLACK wire.

##### Rear window, passenger's side:

cut the 1,5 mm<sup>2</sup> BLUE wire located in the wiring harness coming out of the drivers side door.

#### CENTRAL DOORS LOCKING

##### Additional motor

It is necessary to install a 2 wires motor (art. 1060) as the drivers side door has not an actuating device.

#### IMMOBILISATION POINT

The vehicle has an original equipment immobiliser that may be enabled immediately when the switchboard is switched off.

#### BONNET SWITCH

Install an additional switch on the front headlamp support plate.

#### DOORS SWITCH

Connect to the 0,5 mm<sup>2</sup> WHITE wire located in the wiring harness coming out of the 20 way white connector located on the pillar of the support drivers side.

#### BOOT SWITCH

Connect to the 0,5 mm<sup>2</sup> BLACK wire in the connector that comes out of the boots interior lamp.