



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

HYUNDAI

MOD.

TIBURON

YEAR

96 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the column of the shock absorber, passenger's side. Pass the cables through the original rubber sleeve located on the bulkhead that divides the engine compartment from the passenger's compartment.

POWER SUPPLY

+ 30: connect to the general supply wiring located in the multiway general power supply connector of the fuse box.
- 31: connect with a cable terminal to the car body.

IGNITION WIRE

+ 15/54: connect to the wire marked "+ 15" in the wiring harness directly coming out of the ignition key.

DIRECTION INDICATORS

Connect to the 1 mm² YELLOW/GREEN and GREEN wires located in the wiring harness coming out of the 19 way white connector, on the left of the steering column.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the 2 mm² BLUE/WHITE wire located in the wiring harness coming out of the window switch.

Front window, passenger's side:

cut the 2 mm² YELLOW/BLUE wire located in the wiring harness coming out of the window switch.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the 1 mm² BLUE wire (unlock) and GREEN/YELLOW wire (lock) located in the wiring harness coming out of the central doors locking unit under the dashboard, driver's side.

IMMOBILISATION POINT

Fuel pump

Cut the 2 mm² RED/WHITE wire located in the wiring harness coming out of the pump relay, on the left of the steering column.

STARTER

+50: Cut the YELLOW/RED wire located in the wiring harness coming out of the 6 way light blue connector, near the steering column.

BONNET SWITCH

Install an additional switch on the left lateral bonnet stop.

DOORS SWITCH

Connect to the 1 mm² BLACK/RED wire located in the wiring harness coming out of a white multiway connector, on the left, under the dashboard.

BOOT SWITCH

Connect to the 1 mm² BROWN/RED wire located in the wiring harness coming out of a white multiway connector, on the left, under the dashboard.