



## SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

**REV. 00**

www.cobra.it

MAKE **JEEP** MOD. **CHEROKEE\*** YEAR **03** → PETROL   
 DIESEL

\* Models with original equipment keyless entry system

<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens behind the air filter box, passenger's side.																												
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules under the dashboard, driver's side.																												
<b>POWER SUPPLY</b>	<b>+30:</b> connect to the PINK wire located in the vertical bundle of cables, on the left of the steering column. <b>-31:</b> connect to an original ground terminal located behind the left lateral bulkhead.																												
<b>IGNITION WIRE</b>	<b>+15/54:</b> connect to the BLUE/PINK wire located in the vertical bundle of cables, on the left of the steering column.																												
<b>DIRECTION INDICATORS</b>	Connect to the GREEN/RED and BROWN/RED wires, in the 60 way grey connector, behind the driver's side sill cover.																												
<b>ELECTRIC WINDOWS</b>	<b>Positive control signal</b> <b>Front window, driver's side:</b> cut the 1,5 mm <sup>2</sup> LIGHT BLUE wire in the 14 way grey connector in the push-button panel in the central tunnel. <b>Front window, passenger's side:</b> cut the 1,5 mm <sup>2</sup> BROWN wire in the 14 way grey connector in the push-button panel in the central tunnel. <b>Rear window, driver's side:</b> cut the 1,5 mm <sup>2</sup> BLUE/WHITE wire in the 14 way grey connector in the push-button panel in the central tunnel. <b>Rear window, passenger's side:</b> cut the 1,5 mm <sup>2</sup> GREY/BLACK wire in the 14 way grey connector in the push-button panel in the central tunnel.																												
<b>ACTIVAT./DEACTIVATION CONTROLS</b>	<table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;">Connections antitheft/vehicle</th> <th style="text-align: left;">Art. 3800</th> <th style="text-align: left;">Vehicle</th> <th style="text-align: left;">Position</th> </tr> </thead> <tbody> <tr> <td>YELLOW/BLACK</td> <td></td> <td>PINK/BLACK</td> <td>Horizontal wiring harness on the left of the steering column</td> </tr> <tr> <td>GREY/BLACK</td> <td></td> <td>ORANGE/BLACK</td> <td>Horizontal wiring harness on the left of the steering column</td> </tr> <tr> <td>VIOLET</td> <td></td> <td>BROWN/RED</td> <td>60 way grey connector behind driver's side sill cover</td> </tr> <tr> <td>ORANGE</td> <td></td> <td>ground</td> <td>car body</td> </tr> <tr> <td>VIOLET/WHITE</td> <td></td> <td>ground</td> <td>car body</td> </tr> <tr> <td>ORANGE/WHITE</td> <td></td> <td>ground</td> <td>car body</td> </tr> </tbody> </table> <p>Refer to the <b>A diagram</b> in the dedicated installation manual inside the kit of the antitheft.</p>	Connections antitheft/vehicle	Art. 3800	Vehicle	Position	YELLOW/BLACK		PINK/BLACK	Horizontal wiring harness on the left of the steering column	GREY/BLACK		ORANGE/BLACK	Horizontal wiring harness on the left of the steering column	VIOLET		BROWN/RED	60 way grey connector behind driver's side sill cover	ORANGE		ground	car body	VIOLET/WHITE		ground	car body	ORANGE/WHITE		ground	car body
Connections antitheft/vehicle	Art. 3800	Vehicle	Position																										
YELLOW/BLACK		PINK/BLACK	Horizontal wiring harness on the left of the steering column																										
GREY/BLACK		ORANGE/BLACK	Horizontal wiring harness on the left of the steering column																										
VIOLET		BROWN/RED	60 way grey connector behind driver's side sill cover																										
ORANGE		ground	car body																										
VIOLET/WHITE		ground	car body																										
ORANGE/WHITE		ground	car body																										
<b>IMMOBILISATION POINT</b>	<b>Ignition locking</b> Cut the YELLOW/RED wire in the wiring harness coming out of the 2 way green connector located on the clutch pedal.																												
<b>STARTER</b>	<b>+50:</b> Cut the YELLOW wire in the wiring harness of the ignition key.																												
<b>BONNET SWITCH</b>	Connect to the BROWN/LIGHT BROWN wire at the position nr.6, in the 26 way grey connector, on the back of the central located on the left of the steering column near the door.																												
<b>DOORS SWITCH</b>	Connect to the LIGHT BROWN wire (ant. left) at the position nr.4 and to the LIGHT BROWN/WHITE wire (ant. right) and (post.left and right) at the position nr.5, in the 26 way grey connector, on the back of the central located on the left of the steering column. <b>NOTE:</b> separate the lines with diodes.																												
<b>BOOT SWITCH</b>	Connect to the LIGHT BROWN/BLACK wire at the position nr.7, in the 26 way grey connector, on the back of the central located on the left of the steering column, near the door.																												