



## CAR SECURITY

### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE	MOD.	YEAR	PETROL	DIESEL
<b>KIA</b>	<b>CARNIVAL</b>	<b>99</b> →	<input checked="" type="checkbox"/>	<input type="checkbox"/>
<b>ALARM/SIREN POSITION</b>	Position the compact alarms and the sirens in the engine compartment, on the support of the shock absorber, driver's side.			
<b>CENTRAL UNIT POSITION</b>	Position the modular systems and the modules on the left, under the dashboard, driver's side.			
<b>POWER SUPPLY</b>	<b>+ 30:</b> connect to the 4 mm <sup>2</sup> RED wire located in a multiway connector, in the fuse box. <b>- 31:</b> connect with a ring terminal directly to the car body.			
<b>IGNITION WIRE</b>	<b>+ 15/54:</b> connect to the wire at the position marked "+15/54" directly in the wiring harness coming out of the connector of the ignition key.			
<b>DIRECTION INDICATORS</b>	Connect to the GREEN wire at the position nr. 13 and to the LIGHT BLUE wire at the position nr. 14 located in the 14 way white connector on the rear of the check control.			
<b>ELECTRIC WINDOWS</b>	<b>Front window, driver's side:</b> cut the BLUE and WHITE wires located in the wiring harness coming out of the 9 way white connector on the push-button panel of the driver's side door. <b>Front window, passenger's side:</b> cut the RED/YELLOW and GREEN wires in the wiring harness coming out of the 12 way white connector, above the fuse box. <b>Rear window, driver's side:</b> cut the RED and WHITE wires in the 10 way white connector coming out of the push- buttons near the wing mirror. <b>Rear window, passenger's side:</b> cut the GREEN/YELLOW wires in the 10 way white connector coming out of the push-buttons near the wing mirror.			
<b>CENTRAL DOORS LOCKING</b>	<b>Negative control signal with wire interruption</b> It is necessary to cut the YELLOW/BLACK wire located at the position nr. 12 in the 12 way white connector, behind the driver's side sill cover, above the fuse box. Please refer to the <b>diagram nr. 61</b> .			
<b>IMMOBILISATION POINT</b>	<b>Fuel pump</b> If the vehicle has the inertial switch, it is suggested the interruption of one of the two wires coming out from the same.			
<b>STARTER</b>	<b>+50:</b> Cut the wire located at the position marked "+50" directly in the wiring harness coming out of the ignition key.			
<b>BONNET SWITCH</b>	Install an additional switch on the front headlamp support plate.			
<b>DOORS SWITCH</b>	Connect to the GREEN wire at the position nr. 1 in the 14 way white connector located on the rear of the check control.			
<b>BOOT SWITCH</b>	Connect to the GREEN/BLACK wire at the position nr. 8 in the 14 way white connector located on the rear of the check control.			



## CAR SECURITY


### SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

### FITTING DIAGRAM N° 61

To make the central doors locking on  
KIA CARNIVAL mod. 2000 (with serial radio control)  
(for " Bridge" car alarms)



#### Negative control signal with wire interruption

To make the central doors closing it is necessary to cut the YELLOW/BLACK wire located at the position nr. 12 in the 12 way white connector behind the driver's side sill cover, above the fuse box.  
Note: On vehicles without radio control, install a 2 wires actuating device inside the driver's side door.