

MAKE

LANCIA

MOD.

PHEDRA

YEAR.

02 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment along the coolant bowl. Pass the cables using the oval rubber core hitch above the right front shock absorber, behind the covering. It is suggested to take down the passenger's side glove compartment.

CENTRAL UNIT POSITION

Position the modular systems and the modules under the left side of the dashboard, driver's side.

POWER SUPPLY

+30: connect to the 4 mm² RED wire located in the multiway fuse box.
-31: connect to the original ground terminal located behind the driver's side left lateral bulkhead.

IGNITION WIRE

+15/54: connect to the 1,5 mm² PINK/RED wire, at the position nr. 2, in the wiring harness coming out of the 16 way green connector, in the fuse box.

DIRECTION INDICATORS

Connect to the WHITE wire at the position nr. 13, and to the BROWN wire at the position nr. 14, located in the 16 way black connector, in the fuse box.

ELECTRIC WINDOWS

Positive control signal

To obtain the windows closing it is necessary to intervene directly in the wiring harness coming out of each motor, inside to each door.

CENTRAL DOORS LOCKING

Original door motor direct control

Refer to the **fitting diagram nr.176 - 'B' section** - for the 7900 serie antithefts and to the **fitting diagram nr. 176 - 'A' section** - for the 3100 and 3900 series antithefts.

IMMOBILISATION POINT

Fuel pump

Cut the 1,5 mm² BLUE wire located in the connector coming out of the ignition key.

BONNET SWITCH

Install an additional switch on the headlamp support plate, near the bonnet bumper rubber.

DOORS SWITCH

Connect to the BROWN wire, at the position nr. 32, coming out of the 40 way white covering connector, in the BSI central.

Note: it is a control with positive polarity.


BOOT SWITCH

Connect to the LIGHT BLUE wire, at the position nr.16, located in the wiring harness coming out of the 40 way grey connector, in the BSI central.

FITTING DIAGRAM NR.176

**Diagram to connect the central locking with
3100 and 3900 series antithefts**

'A' Section



'B' Section

**Diagram to connect the central locking with
Bridge serie antithefts**

