



CAR SECURITY

SPECIFIC VEHICLE ALARM FITTING INSTRUCTIONS

REV. 00

www.cobra.it

MAKE

MAZDA

MOD.

626

YEAR

98 →

PETROL
DIESEL

ALARM/SIREN POSITION

Position the compact alarms and the sirens in the engine compartment, on the bulkhead of the support of the left shock absorber. Pass the cables through the rubber sleeve above the lung of the servobrake.

POWER SUPPLY

+ **30**: connect to the 4 mm² WHITE/RED wire located in the multiway connector, at the rear of the fuse box.
- **31**: connect to the car body.

IGNITION WIRE

+ **15/54**: connect to the 2,5 mm² BLUE wire located in the wiring harness coming out of the 8 way connector, in the lower part, behind the fuse box.

DIRECTION INDICATORS

Connect to the 1 mm² GREEN/WHITE and GREEN/BLACK wires with SILVER references located in the bundle of cables coming out of the steering column.

ELECTRIC WINDOWS

Positive control signal

Front window, driver's side:

cut the RED/BLACK wire.

Front window, passenger's side:

cut the GREEN/WHITE wire with LIGHT BLUE references.

These wires are located in the wiring harness coming out of the respective switches.

CENTRAL DOORS LOCKING

Negative control signal

Connect to the GREY/RED wire (lock) and WHITE/BLACK wire (unlock), located in the wiring harness coming out of the multiway connector of the green central doors locking unit positioned on a bracket near the clutch pedal.

IMMOBILISATION POINT

Electronic central unit

Cut the 0,5 mm² BLACK/WHITE wire with SILVER references located in the wiring harness coming out of the 8 way connector, behind the fuse box (it is the first of the three wires starting from the lower part).

BONNET SWITCH

Install an additional switch on the headlamp support plate, using the original hole near the left lateral bonnet stop.

DOORS SWITCH

Connect to the 1 mm² RED/WHITE wire located in the wiring harness of the 3 way connector, in the front part of the fuse box.

BOOT SWITCH

Connect to the 1 mm² BLACK/BLUE wire located in the wiring harness coming out of the right lamp in the boot.